

INDO CHANCERY - Installation Instructions



* Carefully review this document before installing or maintaining the unit *



Input:	240VAC, 50Hz
Weight:	<12kg (all variants)
Windage:	<0.18m ²
Design Mounting Height:	Up to 8m
Mounting Options:	60-76mm post top (PT)
Penetration Requirement:	70mm PT
Tools Required:	Small flat head screwdriver Torque wrench with M10 socket head
Cleaning/Maintenance:	Clean with a damp lint free cloth. Do not use cleaning agents. Any debris on the top surface of the fitting should be washed out.

The light source contained in this luminaire shall only be replaced by the manufacturer or his service agent or a similar qualified person. This is a Class I luminaire and must be Earthed. High voltage testing can cause damage to the LED fittings – use appropriate installation test method.

1. ISOLATE MAINS AND OBSERVE ALL SAFE WORKING PRACTICES BEFORE ATTEMPTING ANY WORK

2. Fit luminaire to the column

The CHANCERY comes with 7m of 3-core cable fitted.

Feed the cable down the column.

Lower the luminaire on to the column.



Orientate the fitting so the directional arrow is facing across the road or in the direction required.

(Remove label after installation)

Ensure luminaire is level, tighten the 8no. M10 grub screws incrementally using a torque wrench to **8-10 Nm** (+/-0.5Nm).

Connect supply in the base of the column

