

# INDO RADIUS - Installation Instructions

INDO

MADE IN  
BRITAIN

\* Carefully review this document before installing or maintaining the unit \*



**Input** 240VAC, 50Hz  
**Weight:** 6.5kg (all variants)  
**Windage:** < 0.2m<sup>2</sup>  
**Design Mounting Height:** Up to 6m  
**Mounting Options:** 60-76mm post top (PT) only  
**Penetration Requirement:** 80mm  
**Tools Required:** Small flat head screwdriver  
Torque wrench with M10 socket head

**Cleaning/ Maintenance:** Clean with a damp lint free cloth. Do not use cleaning agents. Any debris on the top surface of the fitting should be washed out.

The light source contained in this luminaire shall only be replaced by the manufacturer or his service agent or a similar qualified person. This is a Class I luminaire and must be earthed. High voltage testing can cause damage to LED fittings - use appropriate installation test method.

## 1. ISOLATE MAINS AND OBSERVE ALL SAFE WORKING PRACTICES BEFORE ATTEMPTING ANY WORK

### 2. Installation & wiring

The fitting can be fitted to 60mm or 76mm post top. The unit is supplied pre-cabled so it is not necessary to remove the top cover. To install, ensure the mains cable is fed into the column and lower the unit into place. Ensure the cable is not trapped.

Hold the unit in position and tighten all 3no. grub screws by hand and then use a torque wrench to tighten up to 8-10 Nm (+/-0.5Nm).

Connect the wire at the base of the column

